

INSTALLATION & MAINTENANCE MANUAL

SLIDING GRILLES



SLIDING GRILLE INSTALLATION INSTRUCTIONS

Amstel Manufacturing

BEFORE PROCEEDING -

→ SITE VERIFICATION

BEFORE YOU UNPACK THE GRILLE, CHECK THE DOCUMENT PACKAGE ACCOMPANYING THESE INSTRUCTIONS AGAINST YOUR FIELD REQUIREMENTS.

VERIFY THAT THE RECEIVING STRUCTURE IS CAPABLE OF SUPPORTING A FULLY STACKED GRILLE AT ANY POINT ALONG ITS LENGTH.


DO NOT BEGIN INSTALLATION UNTIL YOU ARE SATISFIED THAT ALL OF THE INFORMATION AND MATERIEL PROVIDED ARE CORRECT.

1st) CHECK YOUR PACKING SLIP AGAINST THE SHOP DRAWING TO CONFIRM GRILLE TYPE, FINISH AND QUANTITIES OF COMPONENTS.

2nd) CHECK THE HEIGHT AGAINST THAT ON THE SHOP DRAWING. IF THERE IS A SIGNIFICANT DISCREPANCY, CONTACT THE GRILLE DEALER IMMEDIATELY.

3rd) CHECK THE WIDTH AGAINST THAT ON THE SHOP DRAWING. IF THERE IS A SIGNIFICANT DISCREPANCY, CONTACT THE GRILLE DEALER IMMEDIATELY

	SLIDING GRIL	LE PACK	ING SLIP	
		SIZE	WEIGHT	
Custom			INSTRUCTOR 50021-19S	1
Tag:	A OF 1 Grille: Lexan Vi		Finish: Clear Anodized	
5			26637-16	
2	Grille Sections X 9	Panels x	Lexan Vista Contact Grille Type	e
2	Grille Sections x 10	Panels x	Lexan Vista - AS200AATC Grille Type	e
	Grille Sections x	Panels x	Grille Type	e
	Grille Sections x	Panels x	Grille Type	e
	Fille Sections x	Panels x	Grille Type	e
	Grille Sections x	Panels x	Grille Type	e
	Grille Sections x	Panels x	Grille Type	e
	x Top & Bottom Lock Post (#2)			
	x Intermediate Lock Post (#3)			
2	x Intermediate Lock Post (#4)		SPRING KNOB INSIDE	
2	k Self Locking End Post (#6)			
7	x Hookbolt End Post (#7)			
	x Wall Striker			
	x Fixed End Post (#8)			
1	x BI-Part (#5) SPRING KNOB IN, CYLINDER BOTH SIDES			
	x Bi-Part (#5)			
	X Man Door Egress			
28	x Feet Straight Track		10'-0" , 2 ⊗ 4'-0"	
2	Curves 14.625" Radius @ 90-D	egrees		
	Curves			
6	Track Plates12Track	Pins 40 #10	X 2" Round Head Wood Screws	
32	1" x #8 TEK Point Screws			
3	Floor Sockets 2	V-Stop	Keys - 253	3 sq.ft





TRACK INSTALLATION


NOTE!!

DO NOT INSTALL YOUR GRILLE UNLESS THE STRUCTURE IS ABLE TO HOLD UP THE FULLY STACKED GRILLE AT EVERY POINT ON ITS LENGTH.

WOOD THAT IS WELL SUSPENDED (EVERY FOUR FEET) AND OF AT LEAST 1-3/4" THICKNESS IS RECOMMENDED TO SUPPORT SLIDING GRILLE TRACKS.


DRYWALL FRAMING CHANNEL THAT IS MADE OF STAMPED STEEL IS NOT RECOMMENDED AS A GRILLE SUPPORT, AS THE STEEL WALL GAUGE IS NOT NEARLY THICK ENOUGH TO HOLD ON TO ANY INSTALLATION SCREWS.

THEY WILL PULL OUT OF DRYWALL STEEL..




#10 x 2" SCREW TYP. INTO WOOD (#10 x 1" TEK POINT SCREWS INTO STEEL) SPACED @ 12" (30cm) IN THE OPENING & @ 6" (15cm) IN THE STORAGE POCKETS

GENTLY DE-BURR
INSIDE CUT EDGES
WHERE THE
ROLLERS RUN




TRACK JOINTS MUST
ALWAYS BE TIGHT &
WITHOUT GAPS OR THE
ROLLERS WILL BECOME
DAMAGED


RECESSED TRACK MUST BE REMOVEABLE FOR GRILLE INSTALLATION AND MAINTENANCE




DO NOT PINCH TRACK BETWEEN
DRYWALL SHEETS



DO NOT TAPE OR MUD OVER THE BOTTOM OF THE TRACK



USE "J" MOLD EDGING ALONG RECESSES IN DRYWAY




1st
INSTALL ANY CURVES
AROUND OBSTACLES,
STARTING AT THE

STORAGE POCKET

INSTALL STRAIGHT TRACK
WORKING FROM THE STORAGE
POCKET OUTWARDS. SNAP
CHALK LINES ON ALL FACES TO
ALIGN STRAIGHT TRACK
AND CURVES


IT IS ESSENTIAL TO MAINTAIN 4-1/2" (114mm) CLEARANCE BETWEEN THE CENTERLINE OF THE TRACK AND ANY OBSTACLES. THE GRILLE MUST BE ABLE TO FOLD UP LIKE AN ACCORDION WHEN YOU PUSH IT TOWARDS ITS STORAGE AREA AND IT MUST CLEAR ALL CORNERS.

INSTALL A SHORT
PIECE OF TRACK IN AN
ACCESSIBLE LOCATION
SO THAT THE DOOR IS
EASILY REMOVEABLE
FOR SERVICE AND
MAINTENANCE.






SLIDING GRILLE INSTALLATION






SLIDING GRILLE MAINTENANCE INSTRUCTIONS


1) KEEP THE TRACK
CLEAN AND
REGULARLY
INSPECT IT FOR
DAMAGE.




2) TRACK JOINTS
SHOULD ALWAYS BE
TIGHT AND SECURE
OR THE ROLLERS WILL
BECOME DAMAGED




3) ROLLERS SHOULD CHECKED FOR WE




CLEANING




4) ROLLERS AND TRACK
CURVES SHOULD BE
LUBRICATED WITH A FINE
SPRAY OIL, SUCH AS
WD-40, EVERY FOUR
MONTHS OR AS REQUIRED




5) IF THE TRACK SUPPORT APPEARS TO BE MOVING OR FALLING, REPORT IT IMMEDIATELY TO THE CONTRACTOR RESPONSIBLE FOR ITS CONSTRUCTION.
SUPPORT FAILURE MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE




6) INSPECT HINGE SCREWS
TO ENSURE THAT THEY
REMAIN TIGHT.
DAMAGED HINGES SHOULD
BE REPAIRED OR
REPLACED IMMEDIATELY
OR THE GRILLE WILL NOT
FOLD UP AND OPERATE
PROPERLY.



7) DAMAGED GRILLE SECTIONS
AND COMPONENTS SHOULD
BE REPLACED IMMEDIATELY.
BROKEN PARTS CAN
CAUSE UNDUE STRESSES
DURING THE OPERATION OF
THE GRILLE THAT MAY
RESULT IN INJURY TO THE
OPERATOR OR OTHERS.




8) FLOOR SOCKETS
SHOULD BE KEPT
FREE OF DIRT AND
DEBRIS. LIGHT SPRAY
OIL SHOULD BE
USED OCCASIONALLY
TO FLUSH THEM OUT.




9) KEEP STORAGE POCKETS CLEAN AND FREE OF DEBRIS.

DO NOT STORE OTHER
OBJECTS IN THE POCKET
WITH THE GRILLE AS THEY
MAY CAUSE SUBSTANTIAL
DAMAGE TO IT.



10) CLEAN ALUMINUM SURFACES
WITH A DAMP RAG AND A
NON-ABRASIVE CLEANER.
[ORANGE BASED CLEANERS
WORK WELL ON ANODIZED
ALUMINUM.] TEST CLEANER
ON AN INCONSPICUOUS
AREA FIRST, IF UNSURE.





MAINTENANCE INSTRUCTIONS FOR

SLIDING GRILLES

- 1. Keep track clean and reguarly inspect track for damage.
- 2. Damaged sections should be replaced immediately. Damaged sections cause undue stress during the operation of the grille and can result in injury to the operator and others.
- 3. Inspect hinge screws to ensure that they remain tight. Damaged hinges should be replaced immediately.
- 4. Track joints should always be tight and secure.
- 5. Floor sockets should be kept free of dirt and debris
- 6. rollers should be checked for wear and replaced when needed.
- 7. Rollers and track curves should be lubricated with WD-40 or equivalent type of oil every six months or as required.
- 8. Keep aluminum clean with a damp rag and non-abrasive cleaner. If unsure of cleaner, test it on a small inconspicuous area first. Glass should be cleaned with glass cleaner. If cleaner is spray on to aluminum, wipe off with a damp rag.
- 9. If grille support appears to be moving or falling, this will eventually cause damage to the grille and can result in personal and property damage. Immediately report and bulkhead failures to the contractor responsible for its construction.
- 10. Keep pocket clean and free of debris.
- 11. When operating large sliding grille doors they come equipped with #5 bi-parting post sections. These are there to allow for the end user to separate the grille into smaller sections to reduce the force that is required to push the grille open or closed. If possible it is always better to pull the door extended out to get it to the fully open position or to take it to the mouth of the pocket when closing and then stack the unit up.
- 12. When using s-curves use due diligence and feed the grille carefully through these sections never try to ram a fully stacked door through any curves.

By following these basic steps your grille will last longer with trouble free use for years to come.

If regular inspection and proper maintenance is followed you can help to ensure trouble free use of your Amstel Folding Grille. Please contact us for the availability of maintenance programs. If you have any questions regarding your Amstel Folding Grille, please contact us.



Amstel SLIDING GRILLE EXTRA PANEL REMOVAL

